HASK-P HAZARDOUS AREA SEAL KIT

FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL


INSTALLATION INSTRUCTIONS

DESCRIPTION

The HASK-P Hazardous Area Seal Kit provides the cable termination and explosion proof seal parts needed to make the power end electrical connections associated with Nelson Heat Tracing Systems' self-regulating heater cables. Minimum installation temperature –40°C (-40°F).

KIT CONTENTS

- 1 Junction Box
- 1 Tube of Silicone
- 1 Sealing Compound
- 1 Sealing Grommet
- 1 Conduit Plug
- 2 Pipe Clamps
- 1 Stand-off
- 1 Power Termination
- 1 Terminal Block
- 1 X Fiber
- 1 Seal Fitting
- 1 Male Adapter




HASK-P HAZARDOUS AREA SEAL KIT

FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL

INSTALLATION INSTRUCTIONS


STAND-OFF POSITIONING





Do not install pipe clamps over the heater cable.

- Push heater cable through the bottom opening of the stand-off. Allow 178mm (7") of heater cable for termination. Leave a 305mm (12") loop of additional cable to be installed after the stand-off is secured.
- 2 Mount stand-off to pipe using the pipe clamps included in kit.
- **3** Slide the sealing grommet over heater cable and position at stand-off.




- **4** Secure the additional 305mm (12") of heater to the pipe using fiberglass tape (not included in kit).
- **S** Prepare heater cable for termination. Proceed to "Overjacket Stripping Procedures" on sheet 3.

HASK-P HAZARDOUS AREA SEAL KIT


FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL

INSTALLATION INSTRUCTIONS


OVERJACKET STRIPPING PROCEDURES



- **1** Lightly cut around heater overjacket 178mm (7") from the end. Bend cable to break overjacket.
- 2 Lightly cut overjacket up the center between first cut mark and the cable end. Bend cable to break overjacket.




3 Remove overjacket from heater cable.




4 Move braid back toward the overjacket, creating a bulge.



5 At the bulge, separate the braid to make an opening.



6 While bending the heater cable, work it through the braid opening.




- **7** Pull the braid tight.
- **8** Proceed to "Outer Jacket Stripping Procedures" on sheet 4.

HASK-P HAZARDOUS AREA SEAL KIT


FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL

INSTALLATION INSTRUCTIONS


OUTER JACKET STRIPPING PROCEDURES




- Lightly cut around heater outer jacket 76mm (3") from the end. Bend cable to break outer jacket.
- 2 Lightly cut the outer jacket up the center between the first cut mark & the cable end. Bend cable to break outer jacket.



3 Remove the jacket from the heater cable.




- Starting at the end, pull each bus wire away from the core material.
- **6** Remove exposed core material.



 \bullet Cut 6mm (0.25") off the end of each bus wire.

www.nelsonheaters.com

8 Proceed to "Power Termination" on sheet 5.



MARNING:

DO NOT CUT BUS WIRES

4 Shave the core material from the outside of each bus wire.

PO BOX 726 ■ TULSA, OK 74101 ■ (918) 627-5530 ■ FAX (918) 641-7336

GA-1903 Rev. 7 Sheet 4 of 9 January 2010

HASK-P HAZARDOUS AREA SEAL KIT


FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL

INSTALLATION INSTRUCTIONS


POWER TERMINATION

WARNING:

- Bus wires must not touch or cross while inserting into power termination.
- Only power terminations specifically approved for the vendors style and type of heater cable must be used.



- Insert bus wires into power termination.
- 2 Squeeze power termination opening and fill with silicone.




- **3** Push power termination to overlap jacket.
- **4** Proceed to "Seal Fitting Installation" on sheet 6.

HASK-P HAZARDOUS AREA SEAL KIT

FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL


INSTALLATION INSTRUCTIONS

SEAL FITTING INSTALLATION



• Slide seal fitting over the heater cable and braid, screw onto the stand-off by hand until snug fit.

Note: The heater cable must be positioned in the seal fitting so the braid transition point is visible through the seal fitting opening. See Detail "A" on sheet 8.



Note: If this kit is mounted in an orientation that would allow the sealing compound to flow out, place packing material (X Fiber) around the heater cable.


- 2 Slide male adapter over the heater cable and braid, screw into seal fitting by hand until snug fit.
- **3** Proceed to "Sealing Compound Procedure" on sheet 7.

HASK-P HAZARDOUS AREA SEAL KIT


FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL

INSTALLATION INSTRUCTIONS

SEALING COMPOUND PROCEDURE



• Place junction box over the heater cable and braid, screw onto male adapter until secure.



- 2 Connect bus wires to terminal block, one per terminal. Connect braid to green ground screw.
- Place the box cover gasket and box cover onto junction box. Plug the unused conduit opening with the conduit plug.
- 4 Mix sealing compound according to the instructions on the pouch, (knead to mix liquid and powder in pouch). Snip off a corner of the pouch and fill the seal fitting.

A WARNING:


Sealing compound must completely cover the braid transition point. See Detail "A" on sheet 8 for reference.


HASK-P HAZARDOUS AREA SEAL KIT

FOR DIV. 1 CABLE TERMINATION & EXPLOSION PROOF SEAL

INSTALLATION INSTRUCTIONS

TEMPLATE





Nelson Heat Tracing Systems products are supplied with a limited warranty. Complete Terms and Conditions may be found on Nelson's website at www.nelsonheaters.com.

PO BOX 726 TULSA, OK 74101 (918) 627-5530 FAX (918) 641-7336 www.nelsonheaters.com

NELSON[™]

Nelson Heat Trace

FM Division 1 Checklist for D1-LT and D1-HLT

(or)

Self-Regulating Heater Cable

As required by the Factory Mutual approval process, fill out this form and return to:

Nelson Heat Trace

P.O. Box 726 Tulsa, OK 74101	Fax Number (918) 622-9308	
Company Name		
Purchase Order No.		
Circuit Reference (ID Numl	ber)	
Area Classification Auto Ignition Temperatur	re	
Group		
Substance		
Heater Information Cable Type		
Voltage		
Temperature Identification	on Number (T-rating)	
Termination Kits Power Connection		
End Seal		
Splice Connection		
Tee Connection		
Ground Fault Equipment P Make and Model	Protection (Required)	
Device Trip Level (mA)		
Installation per Manufactur	rers Installation Instructions Initials:	
System Certification		
Prepared By	Company	Date
Prepared By	Company	Date

This completed form must be returned to Nelson to complete the certification process. A copy of this completed form should be kept for installation record retention purposes.



P.O. Box 726 • Tulsa, OK 74101 • 918-627-5530 • Fax: 918-641-7336 • <u>www.nelsonheaters.com</u>